

REPLACEMENT FOR SONY

code **1717**



8 028626 017174

Replacement remote control for Sony TV sets with same symbology as the original one



Blister 12 x 30 x 3 cm
Packaging 30 pcz.



Number of devices	1
Controllable devices	TV SONY
Controls	Controls all functions
Functions	Menu, AV, Teletext, Color
Brands	Compatible with all Sony models
Type of programming	No need of programming. You only have to insert batteries and it is ready to be used.
batteries	2x 1,5 V - AAA (not included)
Code stored	does not lose memory during battery replacement

