

REPLACEMENT FOR GRUNDIG

code 1727



Replacement remote control for Grundig TV sets with same symbology as the original one



Blister 12 x 30 x 3 cm
Packaging 30 pcz.



Number of devices	1
Controllable devices	TV GRUNDIG
Controls	Controls all functions
Functions	Menu, AV, Teletext, Color
Brands	Compatible with all Grundig models
Type of programming	No need of programming. You only have to insert batteries and it is ready to be used.
batteries	2x 1,5 V - AAA (not included)
Code stored	does not lose memory during battery replacement

