

REPLACEMENT FOR HISENSE

code 1720



Replacement remote control for Hisense TV sets with same symbology as the original one



Blister 12 x 30 x 3 cm
Packaging 30 pcz.



Number of devices	1
Controllable devices	TV HISENSE
Controls	Controls all functions
Functions	Menu, AV, Teletext, Color
Brands	Compatible with all HISENSE models
Type of programming	No need of programming. You only have to insert batteries and it is ready to be used.
batteries	2x 1,5 V - AAA (not included)
Code stored	does not lose memory during battery replacement

