## REPLACEMENT FOR TOSHIBA

code 1705



Replacement remote control for Toshiba TV sets with same symbology as the original one





Blister 12 x 30 x 3 cm Packaging 30 pcz.



**Number of devices** 

Controllable devices

Controls

**Functions** 

**Brands** 

Type of programming

batteries

Code stored

**TV TOSHIBA** 

**Controls all functions** 

Menu, AV, Teletext, Color

Compatible with all Toshiba models

No need of programming. You only have to insert batteries and it is

ready to be used.

2x 1,5 V - AAA (not included)

does not lose memory during

battery replacement

