

INSTRUCTION MANUAL

BLUETOOTH SPEAKER



Thank you for choosing **WELL**. Please read carefully the following instructions and keep them within reach.

Reorder No: SPKR-BT-PEALBK-WL / SPKR-BT-PEALGY-WL

Turning on / off the speaker:

1. Turning on: press and hold the power button for 2 seconds , wait for a voice prompt, after which the flashing LED indicator in blue lights up.
2. Shutdown: press and hold the power button for 2 seconds, wait for a voice prompt, after which the LED indicator turns off.

Connect / Pairing:

1. Turn on the music speaker, LED indicator will blink blue in standby mode.
2. Turn on the Bluetooth function on the phone and find the device with the name "CT-331", click on this device to connect. After a successful connection, wait for the voice prompt, after which the LED indicator in blue lights up.
3. The speaker is automatically connected to the phone after turning on the speaker and the bluetooth function on the phone, if previously this connection was used.

Music control:

1. Short press the pause / start button to stop or start music.
2. Short press on “-” to switch to the previous song in the playlist.
3. Short press on “+” to switch to the next song in the playlist.
4. Long press “-” to decrease the volume.
5. Long press “+” to increase the volume.

Package Contents: Wireless Speaker, Micro-USB cable, User Manual

Answer an incoming call: one short press on the button „answer the call / reject a call.“

End a call: one short press on the button "answer the call / reject a call."

To reject an incoming call: hold the button "answer the call / reject a call" for 2 seconds.

Call the last incoming number: double-click on the " answer / reject call. "

* Not all mobile phones support answering and incoming call via a third-party device, in this case, refer to the phone settings.

Charging the speaker:

1. Use a Micro-USB cable
2. Charge the speaker with an input voltage 5V / 1A.
3. Use the cable from the kit to charge the bluetooth speaker
4. The battery capacity may decrease due to the number of recharges. This is a normal phenomenon which is not a manufacturing defect.
5. Charge the speaker if the LED indicator lights up in red, the indicator will turn off automatically after fully charged.

Button layout:

1. Turn on / off the speaker.
2. Next song / increasing volume
3. Pause / Start
4. Answering a call / Rejecting a call
5. Previous song / Decreasing volume
6. Input Micro-USB

Precautions:

1. Read the instructions carefully before use.
2. In order to protect the battery, charge the speaker with an input voltage 5V / 1A.
3. Do not use the speaker near water or in rooms with high humidity. Do not immerse in water or spray water on the music speaker.
4. Store at room temperature.
5. Keep the speaker away from heat and direct sunlight.

Specifications:

Bluetooth: 5.0

Power: 5W

Input current: - DC5V / 1A

Battery capacity - 500 mA / h

Micro-USB port

Sound frequency: 100-16000 Hz


Usage time (assuming an average sound volume) - up to 3 hours

Time for a full charge: 2 hours

Connection range: 10 meters (without obstacles)

Size: 75x75x110 mm

Supported functions: answer / reject / end / cancel an incoming call, adjust the volume, switch songs, turn on / off the the speaker.



Waste electrical and electronic equipment are a special waste category, collection, storage, transport, treatment and recycling are important because they can avoid environmental pollution and are harmful to health. Submitting waste electrical and electronic equipment to special collection centers makes the waste to be recycled properly and protecting the environment. Do not forget! Each electric appliance that arrives at the landfill, the field, pollutes the environment!

**Importer & distributor:**

SC VITACOM ELECTRONICS SRL

CIF: RO 214527

Tel. 0264-438401*

sales@vitacom.ro, www.vitacom.ro